



AvSax®

Flight Deck/Cabin Safety Device

INSTRUCTIONS:

IF POSSIBLE AND AVAILABLE, FIRST DON APPROPRIATE PPE

1. Remove AvSax® from vacuum packing **by pulling on the red strip.**
2. Open the AvSax® by pulling the yellow tab upwards on the front flap of the AvSax®.
3. Lay AvSax® on a flat surface with the opening slightly raised and add a minimum of 1 litre of water, distributing it as evenly as possible to wet the lower inner sides.
4. Turn AvSax® over and repeat step 3.
5. Insert the overheating device and close the flap with battery down if possible.
6. Move AvSax® to an appropriate location.
7. Open a corner of AvSax® and add up to 13 litres of additional water as required to mitigate the effects of the device.
(Do not add more water if device has been put in AvSax® only as a precaution)
8. Reclose flap and monitor AvSax® for the duration of the flight.



AvSax® registration number No.011593258
Patents US7841268



For reorder contact Viking Packing Specialist 800-788-8525.

www.vikingpacking.com